


How to pair products to the We-Vibe App

The We-Vibe app offers seamless connectivity to your We-Vibe toy and exceptional ease of use, letting you and your partner focus on pleasure and stay present in the moment. Whether you're out to dinner, hanging out at home, or travelling for business, the We-Vibe app lets you connect and play.

The We-Vibe app is great for long distance couples, tech-savvy consumers and partners looking for something new and exciting to try.



The Pairing Process

1. To connect your toy in the app, click on the big “+” button under “TOYS – Connect your toy”. From there you can:
 - a. Select Open Camera. You can scan the barcode on the product packaging and follow the on screen instructions to connect your toy.
 - b. Select Connect Through Bluetooth. Follow the on screen instructions to connect your toy.
2. To connect another toy, follow the same steps.
 - a. All connected toys will appear at the top purple section labeled “TOYS”.
 - b. Swipe to the left to see your other connected toys.



We-Vibe Pairing Instructions

Chorus



Please note that you must first pair Chorus to the Squeeze Remote before connecting to the We-Vibe app.

Pair Chorus to remote:

1. Press and hold the control button on Chorus for 10 seconds (Chorus will pulse twice — continue holding the button until the light flashes 3 times).
2. Press and hold the “+” button on the remote until Chorus pairs to the remote (Chorus will pulse 3 times once paired).
3. Press any button on the remote except for the function button (top button with the wave) to feel Chorus respond. If Chorus responds, the remote is successfully paired to Chorus.

Pair Chorus to the We-Vibe app:

1. Click on the big “+” button under “TOYS – Connect your toy”.
2. Select Open Camera or Connect Through Bluetooth.
3. Follow the on-screen instructions to connect Chorus to the app.

You cannot pair Chorus to the We-Vibe app without the Squeeze Remote. Chorus uses AnkorLink™ technology to create a stable connection between Chorus and the app, and the Squeeze Remote is the anchor between this connection. Make sure you keep the Squeeze Remote close by when using the We-Vibe app.

Sync O



Turn on Sync O by pressing the power button. Go into the We-Vibe app and click on the big “+” button under “TOYS – Connect your toy”. Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Please note you cannot be paired to the remote and the We-Vibe app at the same time.

Sync 2



Turn on Sync 2 by pressing the power button. Go into the We-Vibe app and click on the big “+” button under “TOYS – Connect your toy”. Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Please note you cannot be paired to the remote and the We-Vibe app at the same time.

Sync Go



Turn on Sync Go by pressing the power button. Go into the We-Vibe app and click on the big “+” button under “TOYS – Connect your toy”. Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Sync Lite



Turn on Sync Lite by pressing the power button. Go into the We-Vibe app and click on the big “+” button under “TOYS – Connect your toy”. Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Jive 2



Turn on Jive 2 by pressing the power button. Go into the We-Vibe app and click on the big “+” button under “TOYS – Connect your toy”. Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Please note you cannot be paired to the remote and the We-Vibe app at the same time.

Jive Lite



Turn on Jive Lite by pressing the power button. Go into the We-Vibe app and click on the big “+” button under “TOYS – Connect your toy”. Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Moxie+



Turn on Moxie+ by pressing the power button. Go into the We-Vibe app and click on the big “+” button under “TOYS – Connect your toy”. Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Please note you cannot be paired to the remote and the We-Vibe app at the same time.



We-Vibe Pairing Instructions

Melt



Turn on Melt by holding the "+" button. Go into the We-Vibe app and click on the big "+" button under "TOYS – Connect your toy". Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Nova 2



Turn on Nova 2 by holding the "+" button. Go into the We-Vibe app and click on the big "+" button under "TOYS – Connect your toy". Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Wand 2



Turn on Wand 2 by holding the "+" button. Go into the We-Vibe app and click on the big "+" button under "TOYS – Connect your toy". Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Rave 2



Turn on Rave 2 by holding the "+" button. Go into the We-Vibe app and click on the big "+" button under "TOYS – Connect your toy". Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Ditto+



Turn on Ditto+ by pressing the power button. Go into the We-Vibe app and click on the big "+" button under "TOYS – Connect your toy". Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Please note you cannot be paired to the remote and the We-Vibe app at the same time.

Vector+



Turn on Vector+ by pressing the power button. Go into the We-Vibe app and click on the big "+" button under "TOYS – Connect your toy". Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Please note you cannot be paired to the remote and the We-Vibe app at the same time.

Bond



Turn on Bond by pressing the power button. Go into the We-Vibe app and click on the big "+" button under "TOYS – Connect your toy". Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Please note you cannot be paired to the remote and the We-Vibe app at the same time.

Pivot



Turn on Pivot by pressing the power button. Go into the We-Vibe app and click on the big "+" button under "TOYS – Connect your toy". Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

Verge



Turn on Verge by pressing the power button. Go into the We-Vibe app and click on the big "+" button under "TOYS – Connect your toy". Select Open Camera if you have your packaging or Connect Through Bluetooth if you just have your toy. Follow the on-screen pairing instructions.

